

PULMAC
INTERNATIONAL

A Division of Cowan Technologies Inc.

StickyScan™ 100



LCD Monitor, Scanner, Keyboard and Mouse

**Production Test Method -
Quick test with little
training required.**

Description

The StickyScan100 is specifically designed to be used in conjunction with the Pulmac MasterScreen to generate a stickies count based upon on screening contaminants, displaying them on a 22 cm in diameter filter paper, preparing the display, then scanning. Depending on pulp and application a 0.004", 0.006" or 0.008" slotted screen plate may be used.

Benefits

The StickyScan100 will generate simple and effective dirt data for feedback to production operators for abatement efforts. The StickyScan100 is easy to set up, easy to train and simple to interpret data.

Pulmac International
A Division of Cowan Technologies Inc.
32 East State Street, Suite 10
Montpelier, Vermont
05602 USA

Phone: + 1.802.223.2663

Fax: + 1.802.223.2664

Email: info@pulmac.us <<mailto:info@pulmac.us>>

URL: www.pulmac.us <<http://www.pulmac.us>>

StickyScan™ 100

Fast & Easy

Full scan and data output takes less than 1 minute. Just click on "Test" button.

Count	Total Area	Mean Area	PPM
103	30.5	0.180	1002

Location	Description	Sample Date/Time	Grams	Count	Total Area	Mean Area	PPM
Recycled Tissue	PM10 Stuffs Box Late in System	11/12/2003 11:02:51	1000	183	30.2	0.186	1002
Recycled Tissue	PM10 Stuffs Box Late in System	11/15/2003 13:59:48	1000	304	53.5	0.178	1877
Recycled Tissue	PM10 Stuffs Box Late in System	11/15/2003 13:58:18	1000	228	36.6	0.188	1200
Recycled Tissue	FD1 Stuffs Tank Early in System	11/15/2003 13:04:12	1000	450	82.4	0.171	2679
Recycled Tissue	FD1 Stuffs Tank Early in System	11/15/2003 13:00:11	1000	388	67.8	0.191	2384
Recycled Tissue	PM10 Stuffs Box Late in System	11/15/2003 13:01:08	1000	294	46.2	0.163	1624
Recycled Tissue	PM10 Stuffs Box Late in System	11/15/2003 13:12:28	1000	200	29.9	0.148	1047
		11/08/2003 17:58:21	100	9650	23.2	0.022	846
Recycled Tissue	PM10 Stuffs Box Late in System	11/07/2003 14:28:16	1000	183	34.4	0.079	504
Recycled Tissue	FD1 Stuffs Tank Early in System	11/07/2003 14:22:11	1000	230	35.2	0.098	532
Recycled Tissue	PM10 Stuffs Box Late in System	11/07/2003 13:54:39	1000	208	37.0	0.071	587

StickyScan100 screen shot of monitor before running a test.

System Features:

INPUT

- **Enter location:** Drop down box allows location to be selected from a list or entered with keyboard.
- **Enter Description:** Drop down box allows selection of description from a list or entered with keyboard.
- **Enter Time/Date:** Enter with keyboard or use Default of current time/date.
- **Enter sample size:** Enter with keyboard or use default of 1000 g. (data is normalized to 1 Kg)

OUTPUT

- Current test data of "Count", "Total Area", "Mean Area", "PPM" is prominently displayed.
- Image of current scan is displayed.
- Last 11 test results are displayed. Entire history is available using navigation buttons.
- Summary and distribution data are automatically copied to supplied USB Flash Drive.

CALIBRATION

- Verify calibration using supplied reference.

PACKAGE

- PC box, LCD Monitor, Scanner, USB Flash Drive
- Preinstalled operating and application software
- Back up CD and reference sheet

Represented by: **REGMED Indústria Técnica**
 Av. Dr. Alberto Jackson Byington, 1595
 CEP 06276-000, Osaco - Brazil
 Phone + 55 11 3601-5700
 Fax. + 55 11 3601-5973
 regmed@regmed.com.br
 www.regmed.com.br